



Substrate INSTRUCTIONS for Wallboard with Joint Compound on All New Construction
(a.k.a. drywall, plasterboard, Sheetrock®, paperless drywall, etc.)



*The following is a list of primers that have been approved in our test applications. You must use a primer from the list below.

Zero and Low VOC Primers

- Safecoat® Transitional Primer (Zero)
- American Pride or Mythic® Multipurpose Primer (Zero)
- Kilz® Clean Start™ (Zero)
- Mythic® Tintable Accent Primer (Zero)
- Global Green® Stain Blocker Primer (Low)
- Global Green® Wallboard Primer (Low)
- YOLO® Base Primer (Zero)
- Bondz® Maximum Adhesion Primer (Low)
- BioShield® Healthy Living Paints (Low)

Conventional Primers

- Kilz® 2
- Dunn Edwards® Ultra Grip™
- Hamilton Coatings® Prep-Tex

- We will add to this list after successful testing of any additional approved primers.
- American Clay Sanded Primer Elite can still be used instead of our Primer Sand mixed with an approved primer for your application. Lightweight and topping compounds may require a primer coat prior to application. Test in a small area prior to proceeding on the entire project to check suitability of the required preparation.
- Ensure that you follow the manufacturer's suggested directions on the approved primer, especially regarding dry times during humid periods.
- Maintain humidity levels below 50% humidity during application to facilitate drying. For humid climates, dehumidifiers and fans can be used to facilitate this.

To use **ENJARRE - ONE COAT SYSTEM without a binder refer to **TRADITIONAL SYSTEM** substrate preparation.

*** Natural or polymer binder can be PlasterPlus, Up & EZ! or Mud Glue™